AGLV3 CAMERA SET-UP

Congratulations on purchasing your recent Team Subscription with AthletesGoLive! It is recommended to keep your device charged and powered on so important updates can be automatically pushed to the camera.

INCLUDED IN YOUR BOX:

- **One V3 Camera**
- **Camera Bag**
- **Two Screen Protectors**
- **One power cord and charger.**
- **User Manual**
- **Active SIM cards for both T-Mobile & Verizon (already installed)**
- **SIM removal tool**
- **Two bungee cords**
- **One large foam twist-tie**

ANY QUESTIONS REGARDING THE CAMERA SET-UP OR CONNECTIVITY, PLEASE CONTACT SUPPORT@ATHLETESGOLIVE.COM.

⚠️ *BEST PRACTICE* - 48 hours before every game, when you use this device, please ensure the camera is fully charged and turned on so that critical updates are downloaded.

QUICK START GUIDE

IMPORTANT INFORMATION

YOUR DEVICE HAS AN ACTIVE UNLIMITED DATA PLAN WITH BOTH VERIZON AND T-MOBILE. IT IS IMPORTANT TO NOTE THAT THE DEVICE DOES NOT AUTOMATICALLY CHOOSE THE CARRIER WITH THE BEST SIGNAL. YOU WILL NEED TO DO A QUICK SPEED TEST AT THE FIELD TO FIND THE BEST CARRIER. (SEE STEP 10) TO CHOOSE THE BEST CARRIER, PLEASE SEE BELOW.

STEP 1 — Drop down mobile data settings from status bar. Press and hold the Mobile Carrier Settings

STEP 2 — Press data preference and choose the best carrier to live stream based on your speed test.

PLEASE NOTE - TAKE ADVANTAGE OF OUR OFFLINE RECORDING WHILE STREAMING FEATURE. IF YOU DO NOT HAVE A GREAT CONNECTION, YOU CAN STILL LIVE STREAM THE GAME BUT ALSO RECORD THE GAME AT THE SAME TIME, ENSURING THAT THE ARCHIVE VIDEO HAS NO ISSUES.

To get more information about OFFLINE RECORDING, reach out to Support@AthletesGoLive.com.

STEP 3 — Switch to 4G/LTE if Experiencing Issues with 5G

If you are experiencing issues with your connection and the Mobile data type is switching between 5G and 4G/LTE, open the Mobile Carrier settings, expand the Advanced menu selections, and set the Preferred Network Type to 4G.

QUICK START GUIDE

⚠️ *MAKE SURE TO LOGIN ON YOUR STREAMING DEVICE WITH YOUR STREAMING CREDENTIALS AND YOUR SCORING DEVICE WITH YOUR SCORING CREDENTIALS*

STEP 1 — Ensure that your location has a good internet connection

STEP 2 — Check contents for damage or missing items

If you do have any missing or broken items, contact Support@AthletesGoLive.com

STEP 3 — Turn on Camera (Third button down on the right side of camera)

The power button is the third button down on the right side of camera

STEP 4 — While powering up, you may be asked to select a mobile provider. Select the provider that has the best service in your area.

You have access to both Verizon & T-Mobile networks. You have the option to switch back and forth between networks.

verizon✓

AND

T Mobile

⚠️ The camera DOES NOT automatically switch between mobile providers

QUICK START GUIDE

STEP 5 — When powered up, unlock your camera screen by swiping up

STEP 6 — On your screen, you will see the pre-installed apps. Please make sure your device is powered on for updates

STEP 7 — Tap on "Set Mobile Data Icon" to check your mobile connection and if mobile data is enabled

STEP 8 — Verify Mobile Data is Turned On, then click on "Data warning & limit"

QUICK START GUIDE

Turn off "Set data warning"

Verify Mobile connection with the installed "Speedtest" app. Open and press GO to run a quick test.

- If it shows download and upload speeds, then you have connectivity
- You want to see an upload speed of at least 2.5+ Mbps to use streaming functionality

Locate "Do Not Disturb" icon and enable

- **Pull down to open the Status Bar Menu**

- **Pull down further to Expand Status Icons**

- **Turn on Do Not Disturb**

QUICK START GUIDE

STEP 12 — Long press the Do Not Disturb Icon to open complete dialog box. Set all "Interrupt" settings to "none"

STEP 13 — Tap on People and set Call and Messages to None and CLOSE APP

STEP 14 — Make sure NFC is Turned OFF

STEP 15 — Open the correct AthletesGoLive App for your sport, log in with streaming credentials to use the camera, and mount correctly to fence.

- When mounting the camera to the fence, make sure that the bungee cords secure the camera tightly to the fence.
- Use the yellow tie to support the camera.
- Set the device to landscape and rotate the device COUNTER CLOCKWISE.
- View the image when streaming to ensure the fence is not in view and you have a clear picture of the game.